

1652 IN

ANALOGUE INSULATION TESTER



INSTRUCTION MANUAL

Index	Page
1. Safety Precautions.....	1
2. Safety Notes.....	2
3. Features.....	3
4. Specifications.....	4
5. Why Test is Necessary.....	5
6. Instrument Layout.....	6
7. Simplified Instructions.....	7
8. Preparation for Measurement.....	8
9. Functions	9
10. Battery & Fuse Replacement.....	15
11. Calibration & Servicing.....	16
12. Cleaning & Storage.....	16

1. Safety Precautions

Electricity can cause severe injuries even with low voltages or currents. Therefore it is extremely important that you read the following information before using your analogue insulation tester.

1.1 This Instrument must only be used and operated by a competent trained person and in strict accordance with the instructions. we will not accept liability for any damage or injury caused by misuse or non compliance with instructions and safety procedures.

1.2 This instrument must not be used on live circuits. Ensure all circuits are de-energised before testing, see paragraph 1.8 for details of built-in warning features should your analogue insulation tester be connected to a live system.

1.3 Never open your analogue insulation tester except for battery replacement. (see battery replacement section)

1.4 Always inspect you analogue insulation tester and test leads before use for any sign of abnormality or damage. If any abnormal conditions exist (broken test leads, cracked case, display faulty etc...) do not attempt to take any measurement or use the tester. Return your analogue insulation tester to your nearest distributor for service.

1.5 Never replace the protective fuse with any other than the specified or approved equivalent

1.6 Your analogue insulation tester has been designed with your safety in mind. However, no design can completely protect against incorrect use.

Electrical circuits can be dangerous and / or lethal when a lack of caution or poor safety practice is used. Use caution in the presence of voltage above 24V as these pose a shock hazard.

1.7 Pay attention to cautions and warnings which will inform you of potentially dangerous procedures.

1.8 Your analogue insulation tester has a live circuit warning bleeper. If it is connected to an AC live circuit, a beep of twice the frequency of the voltage present will be heard.

DO NOT proceed to test and immediately disconnect the instrument from the circuit. In addition, the warning light will lit if the voltage is above 100Vdc or 70Vac. When AC voltage is present, before testing, it's value is displayed on the AC scale.

2. Safety Notes

Rated environmental condition

- (1) Indoor use.
- (2) Installation Category .
- (3) Pollution Degree 2.
- (4) Altitude up to 2000M.
- (5) Relative humidity 80% Max.
- (6) Ambient temperature 0°C~40°C.



Meter is protected throughout by double insulation or reinforced insulation.



Warning ! risk of electric shock.



Caution ! refer to this manual before using the meter.

3. Features

- High quality taut band movement.
- Three insulation test voltages:
 - 1- 250Vdc 100M Ω
 - 2- 500Vdc 200M Ω
 - 3- 1000Vdc 400M Ω
- Two continuity test on "Low Ohms": 3 Ω / 500 Ω
- Small and Lightweight.
- AC voltmeter with linear scale up to 600Vac.
- 200mA continuity short circuit current.
- 1mA test current on insulation test at nominal voltage
- Automatic discharge of capacitance and inductive circuit off charge stored in the circuit under test.
- Live Warning and display of external voltage presence.
- Fuse and overload protected.
- On line battery monitoring shows if battery is ok.
- Very low battery consumption.
- On-Load battery check (\pm 205mA load for worst case).
- Operates on six 1.5V AA batteries.
- Mirrored scale for easy and accurate reading.
- Push and turn locking switch for long and hand free testing.
- Supplied with high quality test leads.
- Meets: EN 61010-1 CAT III 600V
EN 61326-1

4. Specifications

Insulation

Test Voltage	250Vdc	500Vdc	1000Vdc
Output ranges on open circuit	0~+10%		
Measuring range	100M Ω	200M Ω	400M Ω
Mid-scale value	1M Ω	2M Ω	4M Ω
Scale Multiplier	x1/2	x1	x2
Accuracy	$\pm 5\%$		
Output short-circuit current	Approx. 1.3mA		

Continuity

Measuring range	3 Ω / 500 Ω
Test leads / fuse zero Ω adjustment by knob	\surd
Output short-circuit current	$\geq 200\text{mA}$
Accuracy	$\pm 1.5\%$ of scale length

AC Voltage

AC voltage range	0~600Vac
Accuracy	$\pm 3\%$ of full scale

General

Voltage Warning	Warning light circuit live lit from 90Vdc/70Vac. Buzzer beep from 24Vac/dc.
Power Source	1.5V(AA) x 6
Dimension	163(L) x 106.3(W) x 58.6(H)mm
Weight	Approx. 513.5g (battery included)
Accessories	Test leads Instruction manual Shoulder belt Batteries Carry case

5. Why Test is Necessary

INSULATION

Every electrical apparatus and installation need to be safe for the user and for the equipment itself.

Electrical conductors of electricity need to be insulated from each other, so that they do not create electrical hazard or unnecessary consumption.

Badly insulated circuits can create leakage current which can be dangerous and trip your GFCI, RCCB or ELCB.

Each country regulate those levels at which the insulation is acceptable.

Generally, insulation resistance measurements are done between each conductor and the earth, and between each conductors.

CONTINUITY

Checking the continuity of wires, complete circuits, connections, closure of contacts, circuit breakers, fuses, bounding resistance of connections, etc... Are all very important

6. Instrument Layout



- ① TEST Button
- ② Continuity Zero OHM Adjust
- ③ Function Selector
- ④ HV Indication
- ⑤ Battery OK/ON Indication
- ⑥ Testing terminals

7. Simplified Instructions

WARNING

This instrument must only be used by a competent trained individual. Consult the full operating instructions. Never press the test button before connecting test leads to circuit to test.

INITIAL CHECKS

1. Switch to "Batt. Check" and depress the test button. If the pointer does not move to "BAT. OK", the battery needs to be replaced before proceeding.
2. Connect test leads to instrument, switch to 3Ω . Press and turn the test button (continuous mode), short the test Leads. The pointer should swing from infinite towards zero. If not, the test leads or fuse (0.5A fast acting ceramic) maybe faulty.

INSULATION TESTS M Ω RANGES

1. Select the desired insulation test voltage range, 250V, 500V, or 1000V.
2. Connect the leads to the instrument and circuit under test.
3. Check the circuit is not LIVE.
4. Press the test button. Read the red M Ω scale directly for 500V, multiply by 0.5 (or divide by 2) for 250V and multiply by 2 for 1000V.

CONTINUITY TESTS - Ω RANGES

1. Select the desired ohm range, 3Ω or 500Ω .
2. Short the test leads, press test button and adjust the ohms zero ADJ to zero the pointer on the 0Ω (green scale).
3. Check the circuit is not LIVE.
4. Connect the test leads to the circuit under test. Press the test button. Read the selected range directly.

GENERAL

- For ac voltmeter, do not press test button, this is the default mode of the instrument.
- AC voltmeter can works without batteries.
- Insulation or continuity mode: for continous operation, press and turn the test button.

SAFETY PRECAUTION

- The circuit must not be LIVE, conduct initial checks first. If at any time , the "LIVE" circuit light is lit, or the warning buzzer sounds - DO NOT PROCEED, the circuit is live.
- Using the instrument in Insulation Mode may leave the circuits charged up if test leads are removed too quickly. Avoid this by releasing the test button while the test leads are still connected to the circuit for a few seconds

8. Preparation for Measurement

Before testing Always check the following.

At Power "ON", check that Bat. OK led lit. and check that there is no visual damage to the Instrument or test leads.

Check the test Leads continuity:

1. Connect the leads to the Instrument.
2. Zero the test leads while on the 2 ohm range.
3. This will indicate your that continuity of the test leads is OK.
4. Verify that the test leads insulation is in good condition

9. Functions

9.1 Battery Check



Turn the function selector to Batt. Check. This function has a load which draw about 205mA when test is performed, and therefore it is doing a worst case battery test. Then, press the test button, the pointer should be in the BAT.OK area. During the test, the bat. OK Led (on line battery check) must lit if the pointer is in the BAT.OK area

9.2 DC Warning

The DC warning buzzer will beep continuously when DC voltage is higher than 30Vdc on the test probes and the test button is Not pressed.

The neon light "circuit live" will lit when the voltage on the test probes is higher than 90Vdc and the test button is not pressed.

9.3 AC Warning

The AC warning buzzer will beep continuously when AC voltage is higher than 20Vac on the test probes and the test button is NOT pressed.

The neon light "circuit live" will lit when the voltage on the test probes is higher than 65Vdc and the test button is NOT pressed.

9.4 AC Measurement

The AC measurement is automatic on this instrument. As soon as AC voltage is present on the test leads, the instrument will display the AC voltage from 20 to 600Vac on the linear scale. When measure AC voltage, the testing duration can not be more than one minute.

Between each test, the insulation tester needs to have a 5-minute break.

9.5 Low Ohms Measurement 0 - 3Ω



Always check for voltage before testing and measuring on a circuit. This instrument is intended for measuring Low Ω and Insulation resistance on unenergized circuits only.

Use the procedure explained at points 9.2, 9.3, 9.4.

The first procedure to follow, is to zero the test leads and the fuse resistance. The instrument is equipped with a Zero Ω Knob. First, short circuit the test leads by connecting them together, then, press the test button and adjust the zero Ω knob until the pointer is precisely on the "0" of the 3 Ω scale. Use the mirror scale to be precise with the pointer.

Connect the test leads to the circuit to be measured. For short test, press button and keep pressed. For long test or hand free measurements, press and turn the test button.

9.6 Low Ohms Measurement 0 - 500Ω



Always check for voltage before testing and measuring on a circuit. This instrument is intended for measuring Low Ω and Insulation resistance on unenergized circuits only. Use the procedure explained at points 9.2, 9.3, 9.4.

The first procedure to follow, is to zero the test leads and the fuse resistance. The instrument is equipped with a Zero Ω Knob. First, short circuit the test leads by connecting them together, then, press the test button and adjust the zero Ω knob until the pointer is precisely on the "0" of the 500 Ω scale. Use the mirror scale to be precise with the pointer.

Connect the test leads to the circuit to be measured. For short test, press button and keep pressed. For long test or hand free Measurements, press and turn the test button.

9.7 Insulation Resistance Measurement @ 250Vdc



Always check for voltage before testing and measuring on a circuit. This instrument is intended for measuring Low Ω and Insulation resistance on unenergized circuits only. Use the procedure explained at points 9.2, 9.3, 9.4.

Connect the test leads to the circuit to be measured and wait for a few seconds. The instrument will automatically discharge any remaining energy which could be present on the circuit, and will check for voltage at the same time.

Once you are sure that the circuit to be tested is not energized, then press the button for a short test duration or press and turn the button for a long test. Once you end the test, allow a few seconds for the Instrument to automatically discharge the circuit.

9.8 Insulation Resistance Measurement @ 500Vdc



Always check for voltage before testing and measuring on a circuit. This instrument is intended for measuring Low Ω and Insulation resistance on unenergized circuits only. Use the procedure explained at points 9.2, 9.3, 9.4.

Connect the test leads to the circuit to be measured and wait for a few seconds. The instrument will automatically discharge any remaining energy which could be present on the circuit, and will check for voltage at the same time.

Once you are sure that the circuit to be tested is not energized, then press the button for a short test duration or press and turn the button for a long test.

Once you end the test, allow a few seconds for the instrument to automatically discharge the circuit

9.9 Insulation Resistance Measurement @ 1000Vdc



Always check for voltage before testing and measuring on a circuit. This instrument is intended for measuring Low Ω and Insulation resistance on unenergized circuits only. Use the procedure explained at points 9.2, 9.3, 9.4.

Connect the test leads to the circuit to be measured and wait for a few seconds. The instrument will automatically discharge any remaining energy which could be present on the circuit, and will check for voltage at the same time.

Once you are sure that the circuit to be tested is not energized, then press the button for a short test duration or press and turn the button for a long test.

Once you end the test, allow a few seconds for the instrument to automatically discharge the circuit.

10. Battery & Fuse Replacement

10.1 Battery Replacement

The batteries are situated under the analogue insulation tester. The BAT.OK LED will not lit when the voltage of the batteries is low.

Disconnect the test leads from the Instrument, remove the battery cover and the batteries.

Replace with six 1.5V R6 or L6 batteries, taking care to observe the correct polarity.


Replace with the new batteries and put the battery cover back.

10.2 Fuse replacement

Remove the battery cover and the batteries first.

Replace with a new fuse.

Only replace with same specification fuse.(0.5A/690V, 6x32mm)



11. Calibration & Servicing

Contact your nearest distributor about calibration certificate and servicing.

Before returning the instrument, ensure that:

- the leads have been checked for continuity and signs of damage.
- the batteries are in good condition.

12. Cleaning & Storage

Periodically, wipe the case with a damp cloth and detergent; do not use abrasives or solvents.

If meter is not to be used for periods longer than 60 days, remove the batteries and store them separately

CAT IV - Is for measurements performed at the source of the low-voltage installation.

CAT III - Is for measurements performed in the building Installation.

CAT II - Is for measurements performed on circuits directly connected to the low-voltage installation.

CAT I - Is for measurements performed on circuits not directly connected to mains.

Due to our policy of constant improvement and development, we reserve the right to change specifications without notice