




2940 CL

AC CLAMP METER



INSTRUCTION MANUAL

Index	Page
1. Introduction.....	1
2. Safety notes.....	2-3
3. Features.....	3
4. Specifications.....	4-6
5. Instrument layout.....	7-8
6. Measurement.....	9-10
7. Maintenance.....	11

1. Introduction

Note

This meter has been designed and tested according to CE Safety Requirements for Electronic Measuring Apparatus, EN 61010-1 EN 61010-2-32 and other safety standards. Follow all warnings to ensure safe operation.

Warning


Read "Safety Notes"(next page) before using the meter.

2. Safety Notes


Read the following safety information carefully before attempting to operate or service the meter.

- Use the meter only as specified in this manual, otherwise the protection provided by the meter may be impaired.
- Always keep hands behind the meter barrier.
- Use extreme caution when clamping around uninstalled conductors or bus bars.
- Never clamp around any conductor carrying a voltage above 600V R.M.S.
- During current measurement to avoid an electric shock accident, do not connect the test leads to the instrument.
- To avoid electric shock when measuring live lines, wear appropriate protective gear, such as insulated rubber gloves and boots.
- Rated environmental conditions:
 - (1) Indoor use.
 - (2) Installation Category II 600V
Category III 300V
 - (3) Pollution Degree 2.
 - (4) Altitude up to 2000 Meter.
 - (5) Relative Humidity 80% Max.
 - (6) Ambient Temperature 0~40°C.

- Observe the international electrical symbols listed below.


 Meter is protected throughout by double insulation or reinforced insulation.

 Warning ! Risk of electric shock.

 Caution ! Refer to this manual before using the meter.

 Alternating current.

 Direct current.

 Earth (ground).

3.Features

- 4000-count LCD.
- Full automatic measurement.
 - AC Current measurement.
 - AC/DC Voltage measurement.
 - Resistor measurement.
- Data Hold function.
- Continuity check.
- Diode measurement.
- Low battery indication.
- Auto-off function.
- Flashlight.
- Safety Standard :
 - EN 61010-1 CAT II 600V / CAT III 300V
 - EN 61010-2-32
 - EN 61326-1

4. Specifications

AC Current

Range	Resolution	Accuracy
400.0A	0.1A	$\pm(2.0\%rdg+5dgt)$ (40~200Hz)
1000A	1A	

AC Voltage

Range	Resolution	Accuracy
4.000V	1mV	$\pm(1.5\%rdg+10mV)$ (40~500Hz)
40.00V	10mV	$\pm(1.5\%rdg+5dgt)$ (40~500Hz)
400.0V	100mV	
750V	1V	

- Input impedance : 10M Ω

DC Voltage


Range	Resolution	Accuracy
4.000V	1mV	$\pm(1.0\%rdg+5dgt)$
40.00V	10mV	
400.0V	100mV	
1000V	1V	

- Input impedance : 10M Ω

Resistance


Range	Resolution	Accuracy
400.0Ω	0.1Ω	±(1.5%rdg+3dgt)
4.000kΩ	1Ω	
40.00kΩ	10Ω	
400.0kΩ	100Ω	
4.000MΩ	1kΩ	
40.00MΩ	10kΩ	±(2.0%rdg+4dgt)

Threshold level (beep sound) : less than 25Ω

- Overload protection :
ACV 750V rms
DCV 1000V
Diode & Ohm 250V rms
- Conductor size : 35mm
- Low battery indication :
"  " sign appears on the display.
- Response time :
Approx. 1 second.
- Sample rate :
Approx. 2 times per second.

- Operating temperature and humidity :
0°C~40°C 80% R.H. Max.
- Storage temperature and humidity :
-10°C~50°C 80% R.H. Max.
- Battery life :
Approx. 100 hours on continuity use.
- Dimension :
183(L) × 62(W) × 20(D)mm
- Weight : Approx 123g (battery included)
- Power source : DC 3V (CR2032) battery × 1
- Accessories :
Instruction manual
Test leads
Soft pouch
Battery

5. Instrument layout



- | | |
|----------------------|------------------------|
| (1) Transformer Jaws | (6) Function Switch |
| (2) Flashlight | (7) Input Terminal |
| (3) Jaw Trigger | (8) SELECT Push Button |
| (4) LCD | (9) Flashlight Button |
| (5) Data Hold Button | (10) Barrier |

(1) Transformer Jaws

Pick up the conductor within the jaws center.

(2) Flashlight

For easier viewing in the dark.

(3) Jaw Trigger

Press to open the jaws.

(4) LCD

$3\frac{3}{4}$ digit LCD with maximum reading of 3999.

(5) Data Hold Button

Freeze the reading for all ranges with "HOLD" indicated.

(6) Function Switch

For function selection

(7) Input Terminal

"+" and "-" terminal

(8) SELECT Push Button

For select function :

a. ACV / DCV

b. Ω / \bullet) / \rightarrow 

(9) Flashlight Button

For flashlight function

(10) Barrier


Provide a protective distance from hands to conductor.

6. Measurement

Before proceeding with measurement, read the safety notes.

(1) AC current measurement

- Set the function switch to " \sim A" range.
- Press the jaw trigger to open the transformer jaws and clamp onto one conductor only.
- Read the display reading directly.



(2) ACV measurement

- Insert the BLACK test lead to (-)terminal and the RED one to the other terminal.
- Set the function switch to " \sim V" range and press the SELECT button, until the " \sim V" symbol appears.
- Connect the test leads to the object to be measured.
- Read the display.

(3) DCV measurement

- Insert the BLACK test lead to (-)terminal and the RED one to the other terminal.
- Set the function switch to " $\overline{\sim}$ V" range.

- Connect the test leads to the object to be measured.
- Read the display.

 Note

Reversing the polarity of the test leads displays a negative value.

(4) Resistance measurement

- Insert the BLACK lead to the (-)terminal and the RED one to another.
- Set the function switch to " Ω / \bullet) / $\rightarrow \vdash$ " range and make sure there is no power in the circuit being measured.
- Connect the test leads to the object under test and read the display directly.

(5) Continuity test

- Insert the BLACK lead to the (-)terminal and the RED one to another.
- Set the function switch to " Ω / \bullet) / $\rightarrow \vdash$ " range and press the "SELECT" button, until the " \bullet) " symbol appears.
- Connect the test leads to the object under test.
- The buzzer will work when the resistance is less than 25Ω .

(6) Diode test

- Turn the function switch to " Ω / \bullet) / $\rightarrow \vdash$ " setting and press the "SELECT" button twice, until the " $\rightarrow \vdash$ " symbol appears.

- Connect the 2940 CL red and black test lead, red test lead should connect Diode (+Anode) black test lead should connect Diode (-Cathode). The display will show the reading.

7. Maintenance

(1) Battery Replacement:

When low battery warning appears, change a new battery as follows:

Disconnect the test leads from the instrument and turn off the power. Unscrew the battery cover and replace with a new battery.

(2) Cleaning and storage:



WARNING

To avoid electrical shock or damage to the meter, do not get water inside the case.

Periodically wipe the case with a damp cloth and detergent. Do not use abrasives or solvents.

If the meter is not to be used for a long time over 60 days, please remove the battery for storage.