



Model 185 LST

LAN Cable Tester



The 185 LCT LAN cable tester is a newly designed tool that can easily test the correct pin configuration of the RJ45/RJ11 modular cables, 10/100 base-T cable and Token Ring cable etc.

By comparing one transmitting end and the corresponding receiving end, the 185 LCT LAN cable tester also can test installed cables far away by using the remote receiving unit.

The 185 LCT provides the variety for wiring check, such as cable continuity, open status, short status and miss-wired.

Features

- Designed for RJ45/RJ11 modular cables, 10/100 base-T cable and Token Ring cable.
- The LAN cable tester can verify cable continuity, open, short circuit and miss-wired.
- The remote receiving unit is available for installed cables far away either on the wall plates or on the patch panels.
- Auto and manual scan functions.
- Ground wire test.
- Lock status function.
- Buzzer sound warning for wire status.
- Display : LED indication for wire status.

Specifications

Display	LED
Operating temperature	0°C ~ 40°C
Dimensions	Master unit: 132(L) × 55(W) × 39(D)mm Remote receiving unit: 74(L) × 30(W) × 25(D)mm
Weight (battery included)	Master unit : 148 g Remote receiving unit : 33g
Power source	9V × 1
Safety standard	EN 61326-1

Accessories

- Instruction manual
- BNC testing cables
- Self-test cable
- Carry case
- Battery
- Multi-wire testing cables (optional)



BNC testing cables

Self-test cable



Multi-wire testing cables (optional)

Hoyt Electrical Instrument Works, Inc.

Phone: (800) 258-3652
Fax: (603) 753-9592
Email: sales@hoytmeter.com

www.hoytmeter.com

23 Meter Street
Penacook, NH 03303



Operations

Loopback test

- Plug one end of the testing cable into the RJ45 jack of sourcing end on the master unit and another end of the testing cable into the RJ45 jack of receiving end on the master unit.
 - Press the " " button, the master unit will start a sequential scanning process if the master unit is in "auto-scanning" mode.
 - Press the " " button, the pin1 LED lamps of the LED indicators will be alight if the master unit is in "manual-scanning" mode.
- Note: When the battery power is low, the testing results may not be correct. Please replace with a new battery.
- You can choose a auto-scanning mode or a manual scanning mode by pressing the "AUTO" button or the "MANU" button.
 - The Lock function is available in "auto-scanning" mode.
 - When the loop is "OPEN", you will hear the sound of the buzzer.


Remote test

- Plug one end of the testing cable into the RJ45 jack of sourcing end on the master unit and another end of the testing cable into the RJ45 jack of the remote receiving unit, then make test.
- Read the testing results from the LED indicator on the remote receiving unit.

Test result


a. Continuity

Pin 3 is continued




b. Open

Pin 4 is opened



c. Short

Pin 5 and 6 are shorted



d. Miss-wired

Pin 1 and 7 are miss-wired

