# Model 4167 MF



## Analog Multifunction Insulation/Voltage/Earth Resistance Tester



#### **Accessories**

Instruction manual Test leads Auxiliary earth spikes Simplified measurement probe Shoulder belt **Batteries** 









AL-36

TEL-1505 S

BET-2800

#### **Features**

- High Quality Taut Band movement.
- Capable of measuring earth resistance and earth voltage.
- 2mA measuring current permits the testing of earth resistance without tripping earth leakage current breakers in the circuit under test.
- Test test leads are supplied as standard accessories for simplified two-wire measuring system.
- Two insulation test voltages(DC): 250V and 500V.
  Alternation voltage measurement.
- Battery life indicator.
- Fuse protected.

## **Specifications**

#### **Earth Resistance**

Measuring system	Earth resistance by constant current inverter 820Hz, 2mA approx.
Measuring Ranges	Earth resistance: 0-12/0-120/0-1200Ω Earth voltage: 0-30V AC 40-500Hz
Accuracy	Earth resistance: ±3% F.S. Earth voltage: ±2.5% F.S.

#### Insulation

Test voltage(DC V)	250V	500V	
• ( )			
Measuring ranges	0-100ΜΩ	0-200ΜΩ	
Output voltage			
on open circuit	Rated test v	oltage +10%	
Short circuit			
terminal current	2mA DC		
terriiriai current			
Accuracy	± 5% of sca	le length	


### **ACV**

AC voltage range	0-600V
Accuracy	± 2.5% of full scale
Line frequency range	40-500Hz

#### General

Dimensions	250(L) × 190(W) × 110(D)mm
Weight	Approx. 1500g (battery included)
Power source	1.5V (AA) × 8
Safety standard	EN 61010-1 CAT III 600V
	EN 61326-1

### **Earth Resistance Measurement**




# Hoyt Electrical Instrument Works, Inc.

23 Meter Street Penacook, NH 03303

Phone: (800) 258-3652 (603) 753-9592 Fax:

Email: sales@hoytmeter.com

#### **Insulation Test Connections**



www.hoytmeter.com

Page 1 (1)